

FAX TX Signal
FAX RX Signal

THDAT
THCLK
THLAT
STB1
STB2

TX0
TX1
TX2
TX3
TXE

KRXD/KTXD
KSCLK/KSCLX
KLATCH
KSTART

CLK

CN501

1	EXHOOK
2	BELL
3	LINE-RLY
4	DCN
5	SPMUTE
6	HOOK
7	MPOS
8	LINEIN
9	LINEOUT
10	SPOUT
11	HSTX+
12	HSTX(-)
13	HSRX(+)
14	HSRX(-)
15	24V
16	5VA
17	A-GND

CN507


1	5VD
2	D-GND
3	MONTRX
4	EXHOOK2
5	BREAK
6	E-RECALL
7	HS-ALC
8	P-SHORT
9	DTMF_IMP
10	SIDE_TONE

32.768KHz

24MHz

TO OPERATION PANEL

TO CIS



FAX TX Signal —
 FAX RX Signal —

~ 12V
 HANDSET SP-PHONE FAX RX

~ 12V
 HANDSET SP-PHONE FAX TX

(HANDSET Tx/Rx AMPLIFIER & AGC & SIDETONE) Not Used

TO TEL LINE

TO EXT. TEL

